

BROTHER MFC-7000 cartridge LC01/3/4BK KIT K36 BK

#1 *EASY - REFILLS*

There are two chambers that we have to refill with ink on this cartridge

Do not place tape over breather hole

Place sticker or tape over the ink exit hole while refilling then remove before printing

#2

Remove the cap With a flat knife or small screw driver by placing between the cap and the cartridge body and then twisting to lever the cap upwards.

View of cartridge after the top is removed

#3

Do NOT touch Large foil seal

After inserting the needle into and thru the small foil seal slowly inject the ink making sure that all the air in the chamber is removed. Then remove the needle and **seal the hole with the tape that is supplied.** Make sure of an air tight seal

Small foil seal

#4 *EASY - REFILLS*

Place cartridge on the yellow pad supplied or news paper incase of spillage

Drill a hole in the centre the cartridge This hole will be plugged with the large plug that is attached to the side of the ink bottle

#5 *EASY - REFILLS*

Push the needle all the way in and very slowly inject the ink into the sponge as you slowly pull the needle upwards

#6 #7

Take the large plug which is attached to the side of the INK BOTTLE And firmly push into the filling hole to ensure an air tight seal.

Replace the cap onto the cartridge

#8

Remove the sticker from the ink exit hole and then wait five or ten minutes Before replacing the cartridge into the printer.

Conduct a print head clean and a nozzle test to confirm everything is ok.

Do not place leaking cartridge in printer