


Instructions

www.easyrefills.com.au

Epson S020093

Kit Code: K17BK



Easyrefills kit

Kit Contents:

- 1 x ink bottle (black)
- 1 x plastic gloves
- 1 x hand drill
- 1 x absorbent pad
- 2 x plugs
- 4 x stickers


Preparation:

- Put on the gloves supplied
- Cover your work area in newspaper in case of accidental spillage.
- Read these instructions thoroughly
- Remove the cartridge from your printer (only do this when ready to refill.)


NB: Ink stains so we would recommend you wear old clothes or an apron when refilling.



Preparation




Place one of the supplied stickers over the ink outlet hole in the base of the cartridge. This will prevent the cartridge from leaking during the refilling process.



Place the cartridge on the absorbent pad provided. Locate point 'A' on the top of the cartridge. This is where you will make your filling hole.


1 Step One



Using the drill tool provided, drill a hole at point 'A'. Once you have penetrated the first layer of plastic you will meet a sponge. Stop drilling when you feel this sponge.

3 Step Three

2 Step Two



Insert the refilling needle through the hole you have just made. Push all the way into the cartridge. Note: You will feel a slight pressure because the cartridge contains a sponge.

4 Step Four

Printer Compatibility:

EPSON STYLUS COLOR 400,500,600,700, EPSON STYLUS PHOTO, PHOTO EX,

Cartridge Stats:

Colour: Black
Ink Capacity: 8 ml
Weight when full: 20 grams

Number of refills per kit:


8 refills per kit

Easyrefills manufacturers all refill kits at it's Queensland headquarters. Importing the finest quality American made inks that are in most cases better than or equal to original manufacturers specifications. Each kit has a shelf life of two years and is covered by a 100% guarantee.

Copyright 2004 Easyrefills. All names and numbers used are registered trademarks of their respective owners.

www.easyrefills.com.au

General Information



S-I-o-w-l-y inject approximately 8ml of ink into the sponge pulling the needle upwards as you fill. **Do not overfill.** Note: This should take \pm 1 minute

5 Step Five



Remove the sticker from the ink outlet hole (see step 1). Install the cartridge into your printer and run the head cleaning utility 3 times (see printer manual). For best results wait 1-2 hours before you resume printing.

7 Step Seven

Q: Cartridge will not print?

A: If the cartridge does not print after refilling, rest the print nozzles on a wet tissue. This will draw ink through the nozzles. Leave for 10 minutes and try printing again.

Q: Prints with streaks through text or image?


A: This could mean that the print nozzles are blocked, therefore preventing ink to flow freely. To correct this problem use the printers cleaning routine. If this does not work, rest the print nozzles on a wet tissue. This will draw ink through the nozzles. Leave for 10 minutes and try printing again.

Q: Ink stains on hands and clothes?

A: To clean your hands, first wash thoroughly in soap and warm water. If the stains persist, try using bathroom cleaner. It may take several washes to remove the ink. There is no real solution to ink stained clothes. However if you are using a dy cleaner, you can tell them the ink is based upon water soluble dye with ethylene glycol added.

Phone Support
1300 730 018

6 Step Six



Insert the plug provided into the refilling hole. Gently squeeze the sides of the cartridge while resealing the hole. An air tight seal must be formed. Cover the hole and plug with one of the stickers provided.

8 Step Eight



Congratulations, by refilling your inkjet cartridges not only are you saving money but you are also helping to save our planet by helping to reduce polluting waste.

2 Trouble shooting