
www.easyrefills.com.au

#14A/#23A/#32/ #34/#42A/#44

Kit Code: K55BK



Kit Contents:

- 3 x 40mls ink bottles (black)
- 1 x plastic gloves
- 1 x absorbent pad
- 1 x drill

*asy*refills

Ш

Preparation:

- Put on the gloves supplied
- Cover your work area in newspaper in case of accidental spillage.
- Read these instructions thoroughly
- Remove the cartridge from your printer (only do this when ready to refill.)

NB: Ink stains so we would recommend you wear old clothes or an apron when refillina.



Remove cartridge and place tape over outlet port to prevent ink drips.



If the refill hole indicated in Step 3 is too small for the refilling needle, use the drill provided to enlarge the hole.



2

Step

Two

Step

Seven

Insert the refilling needle through the hole closest to the copper strip. Note: You will feel a slight pressure because the cartridge contains a sponge.



S-I-o-w-I-y and gently squeeze the ink refill bottle to force ink into the cartridge. The reservoir will need to be filled a few times to make sure cartridge is completely filled.

Step

Three

Step

Four

Trouble shooting

Printer Compatibility:

Z818,X3330,X5250,X7150,X7350,X3350, P915.P6250.Z800.X5200.X7170.X8350. X5470 and more.

Cartridge Stats:

Colour: Black Ink Capacity per chamber: 475 Pages

Number of refills per kit:

6 refills per kit

Easyrefills manufactures all refill kits at it's Queensland headquarters. Importing the finest quality American made inks that are in most cases better than or equal to original manufacturers specifications. Each kit has a shelf life of two years and is covered by a 100% guarantee.

Copyright 2004 Easyrefills. All names and numbers used are registered trademarks of their respective owners.

www.easyrefills.com.au



You can either replace the label or leave it off. If you wish to replace the label, ensure it does NOT cover the drilled filling hole. Remove tape from bottom of outlet port to reuse the cartridge.



Remove tape from the bottom of outlet port and sit on absorbent pad to check for leaks.



6

Step


Prep

 $\check{\omega}$

Replace cartridge and run 1-3 print head cleans. For best results, the cartridge should be left in the printer for 8 hours after refilling to allow the ink to fully saturate the sponge.



Congratulations, by refilling your inkjet cartridges not only are you saving money but you are also helping to save our planet by reducing polluting waste.



- A: If the cartridge does not print after refilling ensure the refill hole is not covered or blocked. Rest the print nozzles on a wet tissue. This will draw ink through the nozzles. Leave for 10 minutes and try printing again.
- Q: Prints with streaks through text or
- A: This could mean that the print nozzles are blocked, therefore preventing ink to flow freely. To correct this problem use the printers cleaning routine. If this does not work, rest the print nozzles on a wet tissue. This will draw ink through the nozzles. Leave for 10 minutes and try printing again.

Q: Ink stains on hands and clothes?

A: To clean your hands, first wash thoroughly in soap and warm water. If the stains persist, try using bathroom cleaner. It may take several washes to remove the ink. There is no real solution to ink stained clothes. However if you are using a dy cleaner, you can tell them the ink is based upon water soluble dye with ethylene glycol added.

> **Phone Support** 1300 730 018

