


Instructions

www.easyrefills.com.au

HP #564/#920

Kit Code: K57BK



Easyrefills kit

Kit Contents:

- 3 x 40mls ink bottles (black)
- 1 x plastic gloves
- 1 x absorbent pad

Preparation:

- Put on the gloves supplied
- Cover your work area in newspaper in case of accidental spillage.
- Read these instructions thoroughly
- Remove the cartridge from your printer (only do this when ready to refill.)

NB: Ink stains so we would recommend you wear old clothes or an apron when refilling.



Preparation




Remove cartridge from printer. Replace the orange cover that came with the original cartridge and secure with a rubber band to prevent ink from dripping out during the refilling process. If you no longer have the orange cap put on a vinyl glove and place your finger over the outlet port.



Peel label of the top of the cartridge. Insert the refilling needle through the hole in the top of the cartridge, known as the "vent hole".

1 Step One



S-l-o-w-l-y and gently squeeze the ink refill bottle to force ink into the cartridge.

3 Step Three

2 Step Two



Once you have refilled your cartridge you will need to keep the orange cap (or your finger) over the outlet for about another minute to allow the sponge to soak up the ink.

4 Step Four

Printer Compatibility:

HP PHOTOSMART B109a,B209a,B901a,B8550, B8553,B8558,C309a,C5324,C5370,C5373,C5380, C8383,C5388,C5390,C5393,C5460,C6300,C6324, C6375,C6380,D5460,D5468,D7560
HP PHOTOSMART PREMIUM
HP OFFICEJET 6000,6500

Cartridge Stats:

Colour: Black
Ink Capacity per chamber: 250 Pages

Number of refills per kit:

6 refills per kit

Easyrefills manufactures all refill kits at it's Queensland headquarters. Importing the finest quality American made inks that are in most cases better than or equal to original manufacturers specifications. Each kit has a shelf life of two years and is covered by a 100% guarantee.

Copyright 2004 Easyrefills. All names and numbers used are registered trademarks of their respective owners.

www.easyrefills.com.au



Remove the orange cap (or your finger) and place cartridge in a bowl or cup that you can tolerate ink dripping in to. Leave here for 5 minutes or so to remove any excess ink the sponge can't absorb.



Replace cartridge(s) in printer and run 1-3 cleaning cycles as per your printer instructions.

5 Step Five



These cartridges have an electronic chip which will indicate to the computer that the cartridge is empty. Click "OK" to the error message. The ink level display will not show correctly, however, you will be able to continue printing.

7 Step Seven

Some HP printers just need you to click through the error message and various warnings. You will need to do this again when the other cartridges run out of ink.

Other HP printers require that you hold the RESUME or RESET button for about 10-15 seconds so that it will now print with the refilled cartridge..

Q: Ink stains on hands and clothes?

A: To clean your hands, first wash thoroughly in soap and warm water. If the stains persist, try using bathroom cleaner. It may take several washes to remove the ink. There is no real solution to ink stained clothes. However if you are using a dry cleaner, you can tell them the ink is based upon water soluble dye with ethylene glycol added.

6 Step Six



Congratulations, by refilling your inkjet cartridges not only are you saving money but you are also helping to save our planet by helping to reduce polluting waste.

Phone Support
1300 730 018

Trouble shooting

General Information