www.easyrefills.com.au

Brother LC-37/57/73/77

Kit Code: K63BK



Kit Contents:

- 2 x 70mls ink bottles (black)
- 1 x plastic gloves
- 1 x absorbent pad
- 1 x Brother refill tool with bottle

Preparation:

*asy*refills

Ш

- Put on the gloves supplied
- Cover your work area in newspaper in case of accidental spillage.
- Read these instructions thoroughly
- Remove the cartridge from your printer (only do this when ready to refill.)

NB: Ink stains so we would recommend you wear old clothes or an apron when refilling.



Transfer ink to the filling bottle making sure there is enough ink in the filling bottle to fill the cartridge but do not fill to the top.



Attach the fitting at the end of the tube over the plunger valve on the cartridge as shown. Push or turn the fitting onto the cartridge to ensure a firm fit.



LC-73

Step

One

2

Step

Two

5

Step

Five

6

Step



LC-77XL

Printer Compatibility:

BROTHER DCP130C, DCP135C, DCP150C, DCP350C, DCP540CN, DCP560CN, MFC235C, MFC240C, MFC240C, MFC4665CW, MFC5460CN, MFC3360C, MFC5860CN, MFC885CW + More

Cartridge Stats:

Colours: Black
Ink Capacity: 20 ml per chamber

Number of refills per kit:

6 refills per kit

Easyrefills manufactures all refill kits at it's Queensland headquarters. Importing the finest quality American made inks that are in most cases better than or equal to original manufacturers specifications. Each kit has a shelf life of two years and is covered by a 100% guarantee.

Copyright 2004 Easyrefills. All names and numbers used are registered trademarks of their respective owners.

www.easyrefills.com.au



Insert the syringe into the top of the bottle. Pull back the syringe as far as you can and then remove the syringe. The ink will flow into the cartridge.



Repeat step 2 until the cartridge is full. The ink level can be seen by looking at the clear sight window on the cartridge.



Step

Thre

Step

0

Prepara

Remove the fitting from the cartridge and insert it into the top of the refill bottle for safe storage. Return the cartridge to the printer and run the head cleaning utility.



Congratulations, by refilling your inkjet cartridges not only are you saving money but you are also helping to save our planet by reducing polluting waste.

Q: Prints with streaks through text or image?

A: This could mean that the print nozzles are blocked, therefore preventing ink to flow freely. To correct this problem use the printers cleaning routine.

Q: Ink stains on clothes?

A: Try applying white vinegar to the affected area immediately, soaking in cold water for half and hour and washing as normal.

1300 730 018

Shooting

Phone Support

Trouble

Step

TWO cont.

Step Four ont

<u>neral</u> Information