


Instructions

www.easyrefills.com.au

HP22/60/61/95/97/901

Kit Code: K70CLR
HP C8728A



Easyrefills kit

Kit Contents:

- 3 x ink bottles (red, blue, yellow)
- 1 x plastic gloves
- 1 x absorbent pad

Preparation:

- Put on the gloves supplied
- Cover your work area in newspaper in case of accidental spillage.
- Read these instructions thoroughly
- Remove the cartridge from your printer (only do this when ready to refill.)

NB: Ink stains so we would recommend you wear old clothes or an apron when refilling.



Preparation




Place the cartridge on the absorbent pad provided. If a few drops of ink leak onto the pad do not worry, this is normal.



Carefully remove the label from the top of the cartridge.


1 Step One



To avoid contamination confirm the colours by using the end of a matchstick or toothpick. Insert the matchstick into the hole as far as possible, remove and check for colouring on stick.

3 Step Three

2 Step Two



Insert the refill needle into the hole containing the ink you wish to refill. Angle the needle toward the print nozzles at the bottom of the cartridge and push down as far as possible.

4 Step Four

Printer Compatibility:

DESKJET 5740, DESKJET 6540, DESKJET 6840, PSC 2355, PHOTOSMART 325, PSC 1610, PHOTOSMART 325, PHOTOSMART 2610, DESKJET 1050, 2050, PLUS MORE

Cartridge Stats:

Colour: Tri-colour (Cyan, Magenta, Yellow)

Capacity per chamber	5ml	6ml	7ml
Cartridge No.	22 28 57 93 901	60 75 95 97	61


Number of refills per kit:

5-8 depending on cartridge being refilled

Easyrefills manufactures all refill kits at it's Queensland headquarters. Importing the finest quality American made inks that are in most cases better than or equal to original manufacturers specifications. Each kit has a shelf life of two years and is covered by a 100% guarantee.


Copyright 2004 Easyrefills. All names and numbers used are registered trademarks of their respective owners.

www.easyrefills.com.au



S-l-o-w-l-y and gently squeeze the ink refill bottle to force ink into the cartridge. This must be done with very little pressure, pulling the needle upward as you go.

5 Step Five



Repeat Steps 4-5 for each colour you wish to refill. Using the absorbent pad clean any foreign materials or excess ink from the top of the cartridge.

6 Step Six



Label may be left off and filling holes exposed so that ink can be drawn through when printing.

7 Step Seven



Install the cartridge into your printer and run the head cleaning utility (see printer manual). For best results wait 8 hours before you resume printing.

8 Step Eight

Q: Ink level Guage does not read full?

A: While your cartridge will print just like a new one, the ink level guage will not read full after a refill.

Q: Cartridge will not print or prints with streaks through text or image?

A: One reason for this could be an air bubble formed in the cartridge during refilling. To solve this problem you can either gently tap the cartridge on the side of the desk or simply leave the cartridge in the printer overnight so the ink moves to the bottom of the cartridge and the air moves to the top. If the streaks continue, this could mean that the print nozzles are blocked, therefore preventing ink from flowing freely. If you have used the printers cleaning routine already, rest the print nozzles on a wet tissue. This will draw ink through the nozzles. Leave for 10 minutes and try printing again.

9

Trouble shooting

Phone Support
1300 730 018

General Information